


Big Chef

COMMERCIAL
RICE COOKER/WARMER



Instructions

PARTS IDENTIFICATION



IMPORTANT SAFEGUARDS

1. Read all instructions carefully.
2. Do not touch hot surfaces. Use handles.
3. To prevent electric hazards, do not immerse cord, plug or rice cooker heating plate in water or other liquid.
4. Close supervision is necessary when any appliance is near children.
5. Unplug appliance from wall outlet when no in use and before cleaning. Allow appliance to cool completely before putting on or taking off pot.
6. Do not operate appliance if cord has been damaged, or if appliance malfunctions or suffer serious damage. In such case, contact manufacturer for repair or adjustment.
7. Never put water or any liquid into the outer pot. Water should be placed only in the inner cook pot.

8. Never plug in the power cord without the cooking pot inside the cooker.
9. Always attach the plug to the cooker first, then plug the power cord into the wall outlet.
10. The use of parts or accessory attachments not recommended by ours may cause hazards. Never use the inner cooking pot other than the provided one.
11. Do not use outdoors.
12. Do not let cord hang over edge of table or counter, or allow it to touch hot surfaces.
13. Do not place appliance on or near gas or electric burner, or in heated oven.
14. Use extreme caution when moving appliances containing hot oil or other hot liquids.
15. Always plug cord into wall outlet. To disconnect, remove by plug, not cord.
16. Do not use this appliance for other than intended use.

CAUTIONS

1. Do not share the electrical outlet with other kitchen appliances while using your rice cooker.
2. Use only the electrical outlet which has proper voltage.
3. While using in the kitchen during busy time or in the low voltage area it will take a longer time for cooking or may cause a certain amount of un-cooked rice on the top portion of the inner pot. To improve this, you should reduce the amount of rice for cooking.

HOW TO USE THE BIG CHEF

1. Please use measuring cup to measure the rice. One big measuring cup attached in this cooker may make 10 bowls of well done rice.

Remark: This measuring cup is five times of general rice cooker measuring cup, i.e. one big cup equals five small cup.

2. Please use other container to wash the raw rice until the water is clear.
3. Clean the burnt-proof pad and place it at the bottom of the inner pot, then pour the washed rice into the cooker smoothly.

Note: Do not let the burnt-proof pad float above.

4. Choose either one of the following two ways to add in proper amount of water:
 - a. Make use of the water ruler calibration of the inner pot.

For example: for 20 cups rice (4 measuring cups of this cooker), add the water to 20 cups calibration indicated on the water ruler, for 30 cups rice (6 measuring cups), add the water to 30 cups calibration.

- b. Make use of the attached measuring cups to add equal amount of water as the rice.

For example: 5 cups of raw rice to add 5 cups of water.

Note: Water amount will be adjusted according to different kinds of rice.

5. Before putting in the inner pot, please read the cautions carefully and observe the following instructions:
 - a. Dry the water inside/outside the cooker.
 - b. Wipe the water outside the inner pot, especially the bottom shall not allow rice or foreign object attached, then place the inner pot inside the cooker.
 - c. Turn the inner pot left and right to make sure the inner pot is placed above the heating plate properly.
6. Place the lid on the inner cook pot.
7. Plug in the wire into the power socket.

8. Press the cook switch down, you will see the "cook" indicator light go on. When the cooking time is finished the switch will automatically pop up and the "warm" indicator light will come on.
9. When the rice is ready cooked, the indicator will go off automatically and get into the warm-up status, then the warm-up indicator will light on. Please do not open the cooker in 15 minutes, let the steam continue to cook the rice much tasteful.

USING AN EXTENSION CORD

A short power cord is provided to reduce the hazard of becoming entangled in, or tripping over a longer cord.

Longer extension cords are available and may be used if care is exercised in their use.

If an extension cord is used please follow these instructions:

1. The marked electrical rating of the extension cord should be equal to or greater than the cooker's (15A or over).
2. The extension cord used, should be a grounding, three wire type (for countries or regions only where this applies.)
3. Arrange extension cord so that it does not hang from, cooking surface, counter or table.
4. Place the extension cord where it cannot be pulled on by children or tripped over accidentally.

UNIQUE FEATURES

1. **EASY ONE TOUCH OPERATION:** A simple push-button/On-Off control switch, assures ease of operation.
2. **AUTOMATIC SHUT-OFF AND WARMING FUNCTIONS:** When the rice is cooked, the rice cooker shuts off and switches automatically to the warm function.
3. **LARGE SERVING QUANTITY:** The measuring cup attached in this cooker, 6 cups may cook 60 bowls of rice or 40 pieces of lunch boxes.
4. **NO BURNT RICE STICKS TO THE BOTTOM:** This cooker is enclosed with a burnt-proof pad to avoid such problem.

KEEP WARM

This rice cooker will keep rice warm automatically provided the power cord remains plugged in and the switch is in the warm position. The indicator light will show what position the switch is in.

- * For safety reasons, always disconnect the power cord from the wall outlet when the cooker is not being used and the warm function is not desired, or when removing the inner cook pot from the outer pot.

STORING LEFT OVER RICE:

- * Do not store rice in the rice cooker and leave on warm for more than 3 hours, as this may rice in the refrigerator and re-heat in the rice cooker by adding some water to the rice, then press the switch to cook.

CHECKLIST WHEN COOKER WON'T START:

1. Check for foreign matter caught between the cook pot and the heating plate.
2. Make sure the cook pot is seated properly inside the cooker body, to ensure proper contact with the heating plate.
3. Make sure the cook switch has been pressed into the down position and the light is on, this indicates the cooker is on "cook."
4. If the lights do not come on after plugging the cord into the cooker and the wall outlet, call the Customer Service number for further assistance.
5. Never use any cooking pot from other brand/model rice cooker. otherwise, the rice cooker will be damaged. (This type of damage is not covered inside the warranty)

CLEANING

1. Un-plug the power cord from the wall before cleaning.
2. DO NOT immerse any part of the outer body into water. Wipe it clean with a dish cloth.
3. To clean the cooking pot, soak in hot sudsy water then gently clean the bottom of the cooking pot with a dish cloth. BE CAREFUL not to press down too hard, or drop anything on the bottom of the cooking pot, as this can cause warping and inhibit the proper functioning of the rice cooker.
4. Wipe the cooker body and cooking pot dry before storing.

SUGGESTION

Make tasty rice as you like it:

1. The tip to wash rice is to use warm water, wash lightly, do not scrub with force, the wash water must be poured out quickly. Usually it takes 2 or 3 times to wash until the rice is clear.
2. The immersion time, after the rice is washed, it must be immersed in water for some time to make tasteful and good smell rice. Usually immerse for 30 minutes will do, while it takes 1 hour in winter time.
3. The adjustment of water amount depending on the quality of the rice (new or old rice). One cup of rice requires 1 to 1.2 cups of water.

Note : Please keep this instruction manual and packing carton for future reference and use.

This burnt-proof pad is for applying to the rice cooker for preventing rice crust from happening. It is in full compliance with the food grade regulations. Please be at ease.

How to use:

Clean the burnt-proof pad and place it at the bottom of the inner pot, then pour the washed rice on the burnt-proof pad smoothly. Do not let the burnt-proof pad float above.

CAUTION : Never put the burnt-proof pad on the electric heating plate in the outer pot.

本防焦墊專用於炊飯鍋，防止鍋耙用，無毒性，符合食品級規範請安心使用。

使用方法：

將防焦墊洗淨後平鋪於內鍋裡，再將洗好之米，輕輕倒入在防焦墊上，勿使防焦墊浮起。

注意：絕對不可將防焦墊置於外鍋體內之電熱盤上

