## PRESSING KITS AND FRUIT SIZES CITROCASA 8000 ADVANCE SERIES



<b>Pressing Kit</b> Be sure to follow the size	Large Pressing Kit (Grapefruit Kit)	Standard Pressing Kit (Orange Kit)	Small Pressing Kit (Lemon/Lime Kit)
specifications given for each pressing kit. Using the wrong size fruit can <b>degrade the quality of</b> <b>the juice</b> and <b>damage the</b> <b>equipment</b> !			
Fruit size: diameter	3.15 - 3.50 in (80 - 89 mm)	2.55 - 3.14 in (65 - 80 mm)	1.96 - 2.55 in (50 - 65 mm)
Fruit per minute	Approx. 40 pieces of fruit	Approx. 40 pieces of fruit	Approx. 40 pieces of fruit
Additional Information Attention: ALL pressing kit parts used must have the <b>same color</b> ! Do not mix parts of different color!	Color: <b>GREEN</b> Suitable for large oranges, smaller grapefruit SOLD SEPARATELY	Color: <b>ORANGE</b> Suitable for regular-sized oranges	Color: <b>YELLOW</b> Suitable for lemons, limes, small oranges SOLD SEPARATELY



## ✓ Follow the size specifications!

- ✓ Do not use frozen fruit or fruit that is too cold!
- ✓ Always use clean, quality juice fruit! Only use citrus fruit!

## SOME TIPS FOR JUICING SMALL AND LARGE FRUIT:

- Be sure to use the proper fruit supply tunnel provided with the kit!
- DO NOT mix parts from different pressing kits. ALL pressing kit parts must have the SAME COLOR!
- Be sure to control the flow of fruit into the juicing area to avoid fruit jams:
  Oblong fruit with pointy ends (e.g. lemons), flat fruit (e.g. tangerines), or large fruit may need staff attention to manage flow.



- OR HOSE DOWN THE MACHINE! At Citrus America, we want to make sure that you can enjoy your juicing equipment for many years to come. To do so, please note the following:
  - FOLLOW THE FRUIT SPECIFICATIONS provided (see other side).  $\checkmark$
  - DO NOT OVERLOAD the fruit basket: max. weight: 46 lb!  $\checkmark$
  - REGULARLY EMPTY THE PEEL BUCKETS to avoid back-up blockages and serious machine damage.  $\checkmark$
  - USE THE ON/OFF BUTTON on the display or on the side of the machine to STOP THE JUICING  $\checkmark$ OPERATION.
    - Do not shut off the main power switch or unplug while the machine is running. This will cause the pressing elements to stop in the wrong position and may require special steps to reset the machine.
  - **CLEAN** THE MACHINE AT LEAST ONCE A DAY to keep it hygienic and safe.  $\checkmark$
  - $\checkmark$ **UNPLUG** THE MACHINE before cleaning it.

DO NOT SPRAY

- **Do not jerk the power cord**. Remove the plug by grasping it.
- FOLLOW THE CLEANING INSTRUCTIONS provided.  $\checkmark$
- USE ONLY FRESH, CLEAN, WARM WATER AND A SOFT TOWEL to clean the HOUSING and the  $\checkmark$ **O-RING SEALS.** 
  - o Do not use chemical cleaning agents. Do not use abrasive scouring pads or cleaners. Chemicals and abrasives will damage the O-ring seals and lead to costly repairs.
- THE PLASTIC FRONT COVER, THE SIDE CHUTES, AND THE JUICE TANK (8000 XB) ARE  $\checkmark$ **HANDWASH ONLY!** 
  - Do not place the front cover, the side chutes, and the juice tank in the dishwasher.
- CLEAN ALL OTHER REMOVABLE PARTS IN THE DISHWASHER or clean them thoroughly by hand.  $\checkmark$
- DO NOT PLACE THE MACHINE UNDER RUNNING WATER.  $\checkmark$
- **ASSEMBLE** THE MACHINE IN THE **REVERSE ORDER** of disassembly.  $\checkmark$ 
  - Hand tighten all screws. Install the blade with the sharp edge up. CAUTION: KNIFE IS SHARP!
- ALWAYS **STABILIZE** THE MACHINE when moving it around on the rolling cabinet.  $\checkmark$ 
  - Move it slowly and carefully over thresholds, drains, uneven floor areas and through narrow spaces.
  - O CAUTION: If not stabilized and moved too fast, THE MACHINE CAN TIP OVER AND BREAK!

TECH SUPPORT: 1-855-MY-CITRO (1-855-692-4876) technical@citrusamerica.com

