

MPORTANT	FOR FUT	ure refere	NCE
----------	---------	------------	-----


Please complete this information and retain this manual for the life of the equipment:

Model #:

Serial #:

Date Purchased:

PARTS LIST Direct Steam Counter Tilting Kettles DC-6 DC-10 DC-12 DC-20



⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.


CROWN FOOD SERVICE EQUIPMENT

A Middleby Company

70 Oakdale Road, Downsview (Toronto) Ontario, Canada, M3N 1V9 Telephone: 919-762-1000 www.crownsteamgroup.com

Printed in Canada





<u>[</u>	TEM_	PART NUMBER	DESCRIPTION	QUANTITY
	1.	3819-1	Trunnion Cap	2
	2.	9061-9	Set Screw, 5/16 -18 x 3/8"	2
	3.	9047-87	Retaining Clip	2
	4.	2-115R	"O" Ring	4
	5.	2-014R	"O" Ring	2
	6.	3796-1	Brass Nut, 1/2 - 14"	2
	7.	2-W0C7	Washer	2
	8.	3-D034	Nut, 1/2 - 14 NPS	2
	9.	3-SC06	Knob	1
	10.	3-SC11	Valve	1
	11.	3520-1	Nylon Foot	1
	12.	9031-7	Acorn Nut 3/8 - 16	1
**	13.	3589-1	Handle, 6 - 12 Gallon	1
		5280-1	Handle, 20 Gallon	1
	14.	2-KB01	Knob	1
**	15.	3799-1	Condensate Leg Assembly, 6 Gallon	1
		3799-2	Condensate Leg Assembly, 10, 12 Gallon	1
		6319-1	Condensate Leg Assembly, 20 Gallon	1
**	16.	3800-1	Steam In Leg Assembly, 6 Gallon	1
		3800-2	Steam In Leg Assembly, 10, 12 Gallon	1
		6320-1	Steam In Leg Assembly, 20 Gallon	1
*	17.	9085-1	"O" Ring Lube, 2 Grams	1

^{*} NOT SHOWN.

^{**} SELECT AS REQUIRED.