





Dis-assembling | CLEANING | Re-assembling

For more detailed information on operation and cleaning, go to www.citrusamerica.com/training



1. Empty fruit basket and fruit supply tunnel. Remove fruit basket by gently turning it to the right.



2. Remove rotation plate.



3. Clean basket area with soft damp towel. Dry. DO NOT CLEAN UNDER RUNNING WATER. DO NOT TAKE OFF.



4. Remove splash protector.




5. Remove **side chutes** by pressing the fastening clips and sliding chutes upward out.

HANDWASH ONLY!




6. Remove **front cover**: pull lower part out and lift away from retaining bolts up top.


HANDWASH ONLY!



7. Loosen cross holder screw and remove **cross** holder and screw as one unit.




8. Pull out cross holder screw →3 parts: cross holder, screw, knife guide.



9. Remove peel ejectors.



10. Remove upper pressing elements.



11. Remove lower pressing elements.



12. Lift knife and pull it out.
CAUTION: BLADE IS
RAZOR SHARP!



13. Open **supply tunnel** locking lever and remove supply tunnel.



14. Remove **double cover** (back plate).



15. Unscrew **SB tap** from machine.




16. Unscrew and separate the upper tap from lower tap. Rinse both parts.



17. Remove ATS system by lifting front edge slightly and pulling it toward you.

HANDWASH ONLY!




2

3

24. Re-installing the ATS System: Ensure that the drive shaft of the ATS belt (1) fits correctly into the drive shaft adapter (2). Use the adjustment screw (3) to install the ATS belt correctly.



19. Unscrew fruit sieve nut and remove **sieve support**.



20. Take off all removable parts on cabinet: peel chutes, grate, peel funnel, drip tray and plate.

- 1. BEFORE CLEANING SWITCH OFF AND UNPLUG JUICER.
- 2. CLEAN JUICER AT LEAST 1X DAY!
- 3. ENSURE THAT ALL PARTS ARE MOUNTED PROPERLY AFTER REASSEMBLY
- 4. IF YOUR JUICER DOES NOT START AFTER INPUT FROM ON/OFF SWITCH, REFER TO THE CONTROL PANEL.
- 5. KEEP THESE INSTRUCTIONS NEAR JUICER!



ALL PARTS EXCEPT FOR THE PLASTIC FRONT COVER, SIDE CHUTES, AND JUICE TANK ARE DISHWASHER SAFE.



FRONT COVER, SIDE CHUTES, AND JUICE TANK ARE HANDWASH ONLY. USE A NON-ABRASIVE DETERGENT AND A SOFT TOWEL FOR CLEANING.

DO NOT SPRAY OR HOSE DOWN THE MACHINE. ONLY WIPE DOWN.

TECH SUPPORT: 1-855-MY-CITRO

(1-855-692-4876)