

Use the washing program every day to avoid grease build up and to guarantee a perfect operating Fri-Jado TDR AC Rotisserie.

IMPORTANT: Use the Fri-Jado cleaning products according this cleaning instruction only. Don't use the bags or cartridges in any other device then the Fri-Jado TDR AC Rotisserie.

For more information check story board, the user manual or go to www.frijado.com/support.




Before starting the cleaning program remove fallen parts and rough fat residues from the bottom filter screens inside the rotisserie.


Starting daily cleaning cycle:

Bag:

1. Open rotisserie door.
2. Make sure your hands are dry.
3. Take one bag with rotisserie cleaning powder from the container.
4. Place bag unopened in the central gutter of the bottom of the rotisserie.



Cartridge:



5. Take the stainless steel cartridge holder from container
6. Place holder on the inner side of the door in the area indicated by the arrow
7. Clamp holder behind the metal strip as indicated
8. Take one cartridge bottle from the container
9. Remove safety strip and open cap of the bottle, do not punch inner seal
10. Place bottle with opened cap downwards in the support as shown
11. Close rotisserie door.

12. Press the left-hand selection button.



- Select **CLEAN** and press **OK**.
- Select **DAILY** and press **OK**.
- Select **YES** and press **OK**.
- Press **START**.

Cleaning program starts.

13. After the cleaning program has finished, take out empty cartridge and dispose. Keep stainless steel holder for future use.
14. Remove deflector plates and filter screens and rinse those manually. (consult story board for more information).
15. Inspect the Rotisserie and clean it manually if necessary.
16. Place filter screens and deflector plates back inside the Rotisserie.



The Rotisserie is now ready for use.