





Dis-assembling | CLEANING | Re-assembling

For more detailed information on operation and cleaning, go to www.citrusamerica.com/training



Turn Off and Unplug your juicer before cleaning.



Ensure that **no fruit** remain in the **Fruit Supply Tunnel** or between the **Pressing Elements**.



Remove the cover of the SB-Tap.



Pull the **SB-Tap** out of the machine.



Turn the SB-Tap Lever clockwise and pull straight out.



Remove the Peel Bucket.



Pull out the **Fruit Sieve Support** then remove the **Fine** and **Coarse Sieve**.



Loosen Front Cover Screws then remove the Front Cover.

CAUTION! HANDWASH ONLY!



Remove the **Fruit Supply Tunnel** by opening the fixation lever.



Remove the Cross Holder by loosening and pulling the screw.



Remove the **Upper Pressing Elements**.



Remove the **Knife** by opening the **Fixation Flap** at the top.

CAUTIONI RISK OF INJURY!




Remove the **Double Cover**.



Remove the Drip Tray.

- 1. BEFORE CLEANING SWITCH OFF AND UNPLUG JUICER.
- 2. CLEAN JUICER AT LEAST 1X DAY!
- 3. ENSURE THAT ALL PARTS ARE MOUNTED PROPERLY AFTER REASSEMBLY
- 4. IF YOUR JUICER DOES NOT START AFTER INPUT FROM ON/OFF SWITCH, REFER TO THE CONTROL PANEL.
- 5. KEEP THESE INSTRUCTIONS NEAR JUICER!



- 1) Front Cover Screws
- 2 Front Cover
- 3 Peel Bucket
- **4** Fruit Sieve Support
- **5** Fruit Supply Tunnel
- **6** Cross Holder
- **7** Upper Pressing Elements
- (8) Knife
- 9 Double Cover
- 10SB-Tap
- 11) Main Power Switch



ALL PARTS EXCEPT FOR THE ACRYLIC FRONT COVER ARE DISHWASHER SAFE.



USE A NON-ABRASIVE DETERGENT AND A SOFT TOWEL FOR CLEANING.

DO NOT SPRAY OR HOSE DOWN THE MACHINE. ONLY WIPE DOWN.

TECH SUPPORT: 1-855-MY-CITRO (1-855-692-4876)